





# BND Head Assemblies



Head Assemblies			
Stock Code	Description	Tip Series	Model
<b>A</b> 4235	Head Assembly	1500	EZQ 200/350A
4335	Head Assembly	7400	PEZ200/300E, EZQ 200/350A

Stock Code	Description	Tip Series	Model
<b>B</b> 4435	Head Assembly	7400	PEZ400E, EZQ 500A
4635	Head Assembly	1500	PEZ600E, H, F

Stock Code	Description	Tip Series	Model
<b>C</b> 5623	Head Assembly	7400	PEZ400W

Stock Code	Description	Tip Series	Model
<b>D</b> 7392	Head Assembly	7400	PEZG